

## PLT-30xx Pre-drilled PLT top inserts

•A1	•A1	A1°	A1°
°C °A2	•A3	43°	C° A2°
°B1	°B2	B2	• B1
∘B1	°B2	B2	• B1
•A2 •C	∘A3	\3 °	A2 ° C °
∘A1	•A1	\1°	A1°

BASE TYPE	MODEL NUMBER	CORRESPONDING INSERTS	
Post Leg	PLTPOSTLEG	A1, A2, A3	
T-Leg	PLTTLEG	B1, B2	
Ganging Hardware	PLT-GC	С	
Breakout Flip Top Nesting Table	PTLF-48. PTLF-60, PTLF-72	B2	
Pneumatic Height Adjustable Table	PTLT-PGLB60NF	A2	
Electric Height Adjustable Table	PLT-EAB4872BUDNF	A2	
Corner Electric Height Adjustable Table	PLT-EACB6078WFER	A2 or A3	

## IMPORTANT

- Place all wooden parts on a clean and smooth surface such as a rug or carpet to avoid parts from being scratched.
- Check that you have all parts and hardware.
- Remove all wrapping materials, including staple and packing straps before you start to assemble.
- Do not tighten any screws or bolts until the unit is completely assembled.
- Keep all hardware parts out of reach children.