



PERFORMANCE
IN TURBINES

This diagram illustrates the exploded view of a chair, showing the seat, backrest, and base assembly. The seat and backrest are shown on the left, while the base assembly, including the central column and five casters, is shown on the right. The diagram highlights the connection points for the seat and backrest to the central column.



Step 3

Step 2

[illegible]

1 of 1

ATTENTION

ATTENTION: Do not tighten any screws or bolts until the unit is completely assembled. Ensure all bolts and screws are tightened before using. Check bolts and screws every 6 months. If any parts are missing, broken, damaged or worn, stop use of product until repairs have been made using factory authorized parts. Failure to follow these warnings may result in injury.