

# ASSEMBLY INSTRUCTIONS

## MODEL: PL150SGD/PL151SGD/PL250SGD



**PERFORMANCE**  
FURNISHINGS

Before assembly, please remove all parts from the carton, verifying that you have the correct quantities, and read all the instructions.


### IN THE CARTON:

1  Glass Pads 4 Pcs	2  Self-Drilling Screws 8 Pcs	3  Handle Screws 4 Pcs	A  Aluminium Glass Door	*4  Hinge Set 3 Pairs	*5  Wood Screws 9 Pcs	*6  Handle 1 Pc
------------------------------	---	---------------------------------	----------------------------------	--------------------------------	--------------------------------	--------------------------




\*HARDWARE FROM PL150/PL151/PL250

### INSTRUCTIONS:

Optional : door can be left or right!





Attach the Door to the  
Side Panel with Hinges.



Stick the Glass  
Pads (1) on the  
Shelf.

PL150/PL250

PL151



For PL151, complete above steps  
as a LH door, and then as a RH door.  
(2 doors required.)

### ⚠ ATTENTION ⚠

Place all wooden parts on a clean and smooth surface such as a rug or carpet to avoid the parts from being scratched.

Check that you have all parts and hardware.

Remove all wrapping materials, including staples & packing straps before you start to assemble.

Do not tighten any screws or bolts until the unit is completely assembled.

Keep all hardware parts out of reach of children. There may be extra hardware when install is complete.