

Please follow these instructions for easy assembly.

◦A1	◦A1	A1◦	A1◦
	◦C		C◦
◦A2	◦A1	A1◦	A2◦
◦B1	◦B2	◦B2	◦B1
◦B1	◦B2	◦B2	◦B1
◦A2	◦A1	A1◦	A2◦
	◦C		C◦
◦A1	◦A1	A1◦	A1◦

PLEASE USE CORRESPONDING INSERTS WITH THE APPROPRIATE BASES.

- 1) Hole A1/A2 – For Post Leg (Model# PLT Post Leg)
- 2) Hole B1/B2 – For T-Leg (Model# PLT T Leg)
- 3) Hole C – For ganging device (Model# PLTGC)
- 4) Hole B2 – For PTLF Flip top base (Model# PTLF)
- 5) Hole A2 – For A-Leg and ARC-Leg  
(Model# PLTALEG-2430 & PLTARCLEG-2430 and PLTALEG4860 & PLTARCLEG-4860)

### **IMPORTANT !!**

- Place all wooden parts on a clean and smooth surface such as a rug or carpet to avoid the parts from being scratched.
- Check that you have all parts and hardware.
- Remove all wrapping materials, including staples & packing straps before you start to assemble.
- Do not tighten any screws or bolts until the unit is completely assembled.
- Keep all hardware parts out of reach of children.