



ASSEMBLY INSTRUCTION FOR 41" END PANEL & MODESTY PANEL FOR PLT TOP


HARDWARE




COMPONENTS



KLIX CAM INSTRUCTIONS





IMPORTANT NOTE:


- Place all wooden parts on a clean, smooth surface to prevent the parts from being scratched.
- Check that you have all parts and hardware.
- Remove all wrapping materials, including staples & packing straps before you start to assemble.
- Do not tighten any screws or bolts until the unit is completely assembled.
- Keep all hardware parts out of reach of children.


PAGE 1 OF 2


REV. 1 PLTEP&PLTMOD_AI




ASSEMBLY INSTRUCTION FOR 41" END PANEL & MODESTY PANEL FOR PLT TOP









PAGE 2 OF 2

PLTEP&PLTMOD_AI